

# BATHTUB MEASUREMENT INSTRUCTIONS

PLEASE RECORD YOUR RESULTS HERE

Measure most tubs in four easy steps

PAGE 1

1. MEASURE DEPTH OF CUT
2. MEASURE LENGTH OF CUT
3. MEASURE TOP WIDTH OF TUB
4. MEASURE BOTTOM WIDTH OF TUB
5. (IF APPLICABLE) MEASURE TUB OFFSET
6. (IF APPLICABLE) MEASURE CURVE OF TUB

NAME \_\_\_\_\_

PHONE \_\_\_\_\_

E MAIL \_\_\_\_\_

DEPTH OF CUT \_\_\_\_\_

LENGTH OF CUT \_\_\_\_\_

LEFT TOP WIDTH \_\_\_\_\_

RIGHT TOP WIDTH \_\_\_\_\_

LEFT BOTTOM WIDTH \_\_\_\_\_

RIGHT BOTTOM WIDTH \_\_\_\_\_

OFF SET MEASUREMENT-- INCHES DOWN \_\_\_\_\_ INCHES OUT \_\_\_\_\_

TUB CURVE -- INSIDE \_\_\_\_\_ OUTSIDE \_\_\_\_\_

**TO SUBMIT FORM**

**[CLICK HERE](#)**

**FOR QUESTIONS OR ASSISTANCE CALL 480 255 1689**

**Measure Most Tubs in 4 Easy Steps!**


1. Measure Depth of Cut
2. Measure Width of Cut
- 3. Measure Top Width of Tub**
- 4. Measure Bottom Width of Tub**
5. (If Applicable) Measure Offset of Tub
6. (If Applicable) Measure Curved Tub

**Tools Needed to Measure Your Tub**

- ▣ Tape Measure
- ▣ Straight Edge
- ▣ Level
- ▣ Pencil & Paper


1. Measure the Depth of the Cut - See FIGURE 1
  - A. Place a straight edge across the top of the tub.
  - B. Measure from the bottom center of the tub to the bottom of the straight edge.
  - C. Deduct 3" from that measurement  
(Ex: 12" tub depth - 3" = 9" deep cut).

FIGURE 1



2. Measure the Length of the Cut - See FIGURE 2
  - A. Determine the location of objects which may interfere with the use of a saw while cutting, such as the toilet or cabinetry.
  - B. The opening may be in the center or offset to either side of the tub. If you would like to offset the opening, stay at least 12" away from the end of the tub.
  - C. Make a start mark on the top edge of the tub. Measure along the top edge of the tub to the length you want the opening, then place a finish mark.

FIGURE 2



3. Measure the Top Width of the Tub See FIGURE 3
  - A. Measure the thickness of the wall, at the top, below the inside and outside rounded edges.

FIGURE 3





FIGURE 4

4. **Measure the Bottom Width of the Tub – See Figure 4**
- On the inside of the tub wall, in line with the start and finish marks, measure down the depth of the cut.
  - Place one end of a level on this mark, level up vertically, and measure from the level to the outside edge of tub.




If you have a standard tub with no Offset and your tub is not Curved, you are finished taking measurements! Please fill out the form and submit so that we can begin building your custom kit right away!

If your tub has an Offset on the outer wall or the outer wall is Curved, please follow the appropriate step below.

5. **Measure the Offset (if Applicable) - See FIGURE 5**
- An offset is a raised, decorative pattern on the outer wall of the tub. If the offset is running horizontally along the tub wall, it will cross the vertical cut lines.
  - Measure from the top of the tub, down to the center of the offset.
  - Then measure how far the offset protrudes from the outer wall of the tub.
  - Make a note of the Offset measurements with reference to the Illustration it matches.

FIGURE 5



6. Measuring a Curved Tub (if Applicable) - See FIGURE 6

- A. Take Depth, Width, Bottom, and Top measurements as outlined in Steps 1 - 4 above.
- B. Set straight edge on top of tub at 90 degrees to left cut line and right cut line.
- C. Measure distance from wall of the tub to inside edge of the straight edge.

